

Z-FLEX "BARBED WIRE" (9.5") TAIL-GUARD FITTING TEMPLATE

DIRECTIONS:

1. Print this page at 100% (do not scale to fit).
2. Cut out the template/s that you need.
3. Hold the template/s in the desired position/s on your deck in order to check that the sizes and shapes are compatible.

